PRODUCT SEAKEEPER 9



DESCRIPTION

Instructions for the unpacking of the Seakeeper 9 shipping crate.

PROCEDURE

- 1. **INSPECT** crate <u>AND</u> NOTE any damage per <u>TB-90740 Seakeeper Crate Receipt Inspection</u>.
- 2. With clip removal tool attached to crate exterior (shown in image), **REMOVE** metal clips at top of crate. [See instructions on ATTACHMENT for details]



- 3. **CAREFULLY REMOVE** lid.
- 4. **REMOVE** four sides of crate.
- 5. **MAINTAIN** Seakeeper bolted to pallet until ready to install.
- 6. **REMOVE** top cover of Seakeeper to access lifting eyes of enclosure:
 - a. **RELEASE** push pins with plastic tool to not scratch painted surfaces.







PRODUCT SEAKEEPER 9

CAUTION:

DAMAGE TO HOSES OR CABLES MAY OCCUR FROM SCREW REMOVAL.

7. When ready to install, **REMOVE** four hex head cap screws (3/8-16 X 4 in.) and associated hardware at each corner of Seakeeper frame with 9/16 in. socket/wrench. [HHC screws circled in image]





PRODUCT SEAKEEPER 9

CAUTION:

DAMAGE TO SEAKEEPER ENCLOSURE MAY OCCUR IF LIFTED BY SHORT SLINGS.

8. **ATTACH** long slings or spreader bar to lifting eyes (as shown in images below) at top of enclosure **AND LIFT** Seakeeper for placement.



9. **RETURN** Quick-Crates to Seakeeper for reuse.

Revision	Description	Approval	Date
4	Added 7HD reference.	BRD	08DEC2016
5	Removed 7HD reference. Updated model image. Updated steps.	A Patricio	29MAR2023

PRODUCT SEAKEEPER 9

ATTACHMENT

Quick-Crate Instructions:



Quick-Crate* is Registered with the U.S. Patent & Trademark Office

