

SEAKEEPER DC SEAWATER PUMP CONNECTOR



PRODUCT SEAKEEPER 5/6 AND SEAKEEPER 9

OVERVIEW:

Seakeeper 5/6 and Seakeeper 9 models starting with serial numbers 5-201-1936 / 6-201-1936 and 9-201-2839, respectively, are equipped with an extra lead apart from the Seakeeper wire harness. The additional connection labeled “DC SW” is currently inactive and should be disregarded at this time. The DC SW cable will eventually be utilized to support connectivity to DC seawater pumps for these Seakeeper models. The conversion to DC seawater pumps for these Seakeeper models is tentatively planned for late 2020 and more information will be provided once the release date is confirmed.

Please follow the below instructions to identify and secure the DC SW lead on the applicable units. The DC SW lead will be secured as described on Seakeeper 5/6 and Seakeeper 9 shipments starting with the following serial numbers: 5-201-2083 / 6-201-2083 and 9-202-2910.

PROCEDURE:

1. At the back of the Seakeeper unit, **IDENTIFY** the lead labelled “DC SW.”
2. **REWORK** the DC SW lead and connector back through the sheet metal grommet and opening.

NOTE: It may be necessary to remove the grommet from the sheet metal.

3. Once inside the Seakeeper cover, **FOLD OVER** the lead onto itself **AND ZIP-TIE** to the main harness branch.



REVISION	DESCRIPTION OF CHANGES	DATE	APPROVED
1	Initial Release	10/12/2020	K. Zervas